



For installation – Please do not splice or cut any of the Wig-Wag harness wires. Use original on-off switch supplied and do not splice into another switch on the bike. In addition, the yellow pursuit wire must be spliced before any relay or flasher that has been splice into the pursuit wire. This Wig-Wag Circuit Harness Assembly must be installed as a complete separate unit on the bike and not spliced into other features or it may affect other bike functions.

For police fleet tech support please call 513-772-3469 or 800-567-8346

For installation – Please do not splice or cut any of the Wig-Wag harness wires. Use original on-off switch supplied and do not splice into another switch on the bike. In addition, the yellow pursuit wire must be spliced before any relay or flasher that has been splice into the pursuit wire. This Wig-Wag Circuit Harness Assembly must be installed as a complete separate unit on the bike and not spliced into other features or it may affect other bike functions.

For police fleet tech support please call 513-772-3469 or 800-567-8346

For installation – Please do not splice or cut any of the Wig-Wag harness wires. Use original on-off switch supplied and do not splice into another switch on the bike. In addition, the yellow pursuit wire must be spliced before any relay or flasher that has been splice into the pursuit wire. This Wig-Wag Circuit Harness Assembly must be installed as a complete separate unit on the bike and not spliced into other features or it may affect other bike functions.

For police fleet tech support please call 513-7723469 or 800-567-8346